§ 93.343

VHF frequency 121.5 or UHF frequency 243.0.

(d) Before departing from an airport within the DC FRZ, or before entering the DC FRZ, all aircraft, except DOD, law enforcement, and lifeguard or air ambulance aircraft operating under an FAA/TSA airspace authorization must file and activate an IFR or a DC FRZ or a DC SFRA flight plan and transmit a discrete transponder code assigned by an Air Traffic Control facility. Aircraft must transmit the discrete transponder code at all times while in the DC FRZ or DC SFRA.

§ 93.343 Requirements for aircraft operations to or from College Park Airport, Potomac Airfield, or Washington Executive/Hyde Field Airport.

- (a) A pilot may not operate an aircraft to or from College Park Airport, MD, Potomac Airfield, MD, or Washington Executive/Hyde Field Airport, MD unless—
- (1) The aircraft and its crew and passengers comply with security rules issued by the TSA in 49 CFR part 1562, subpart A;
- (2) Before departing, the pilot files an IFR or DC FRZ or DC SFRA flight plan with the Washington Hub Flight Service Station (FSS) for each departure and arrival from/to College Park, Potomac Airfield, and Washington Executive/Hyde Field airports, whether or not the aircraft makes an intermediate stop;
- (3) When filing a flight plan with the Washington Hub FSS, the pilot identifies himself or herself by providing the assigned pilot identification code. The Washington Hub FSS will accept the flight plan only after verifying the code; and
- (4) The pilot complies with the applicable IFR or VFR egress procedures in paragraph (b), (c) or (d) of this section.
- (b) If using IFR procedures, a pilot must—
- (1) Obtain an Air Traffic Control clearance from the Potomac TRACON; and
- (2) Comply with Air Traffic Control departure instructions from Washington Executive/Hyde Field, Potomac Airport, or College Park Airport. The pilot must then proceed on the Air

Traffic Control-assigned course and remain clear of the DC FRZ.

- (c) If using VFR egress procedures, a pilot must—
- (1) Depart as instructed by Air Traffic Control and expect a heading directly out of the DC FRZ until the pilot establishes two-way radio communication with Potomac Approach; and
- (2) Operate as assigned by Air Traffic Control until clear of the DC FRZ, the DC SFRA, and the Class B or Class D airspace area.
- (d) If using VFR ingress procedures, the aircraft must remain outside the DC SFRA until the pilot establishes communications with Air Traffic Control and receives authorization for the aircraft to enter the DC SFRA.
 - (e) VFR arrivals:
- (1) If landing at College Park Airport a pilot may receive routing via the vicinity of Freeway Airport; or
- (2) If landing at Washington Executive/Hyde Field or Potomac Airport, the pilot may receive routing via the vicinity of Maryland Airport or the Nottingham VORTAC.

§ 93.345 VFR outbound procedures for fringe airports.

- (a) A pilot may depart from a fringe airport as defined in §93.335 without filing a flight plan or communicating with Air Traffic Control, unless requested, provided:
- (1) The aircraft's transponder transmits code 1205:
- (2) The pilot exits the DC SFRA by the most direct route before proceeding on course; and
- (3) The pilot monitors VHF frequency 121.5 or UHF frequency 243.0.
- (b) No pilot may operate an aircraft arriving at a fringe airport or transit the DC SFRA unless that pilot complies with the DC SFRA operating procedures in this subpart.

Subpart W—New York Class B Airspace Hudson River and East River Exclusion Special Flight Rules Area

SOURCE: 74 FR 59910, Nov. 19, 2009, unless otherwise noted.